

Figure 4

## STEP 5 - Install Celling Canopy to Celling

A. Carefully tuck all wires into the outlet box and position the ceiling canopy of the Fixture Body (A) over the outlet box. Align the holes in the ceiling canopy with the Mounting Screws (DD).
Secure with Mounting Balls (AA) and hand tighten until snug.



