For Style 6603C24C Assembly Instruction Sheet #IS-6603C24C

Required: Flathand acrewidher, Pfillips acrewidher, plans, wire culturs, wire altippers, electrical tops, safety glesses ownes: (8) GU10 BULB 36W MAX (hot include). lad Assembly Time: 20-30 minutes

areflont Identify and Inspect all parts before beginning Installation. Check package content list and diagrams below to be sure all parts are int. If any parts are missing or damaged, do not attempt to assemble, Install, or operate the fidure. Context customer service for replacement

These instructions are provided for your eafety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before remove

A. Line up a set of holes on the STEP 1 — Attach Mounting Screws, Lock Washers and Hex Nuts to Mounting bracket. Package Contents Hardware Contents and fighton until any ing braciest (EE) and Hole Mounting Screws (DD) A Flature Body x1 Figure 1 11111 Ä 8 A. Pase the supply wires through the Mounting bracket (EE).

Attach the Mounting bracket (EE) to the Outlet Box STEP 2 - Attach Mounting bracket to Outlet Box and proceed to Step 4. STEP 3 — Fit Ceiling Canopy to Mo.

A.Fit the ceiling canopy to Mounting Screw canopy is secure, remove the Cap nut (AA) and ceiling canopy with Cap nut (AA). Note: The ceiling canopy should be amug against he ceiling and the Cap nut (AA).If not, adjust the length of the set $(\Xi\Xi)$ until the correct length is achieved. Once the ce**lling** ad of the Green Ground Screw facing you. Supply Wires with Outlet Box Screws Ground Wire Figure 3 Figure 2 y to Mounting bracket Asing Screws (DD) and secure ve (DD) in or out of the Mounting 8 Calling Canopy 84

